





<b>Last Modified:</b> 07-05-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000002K9IV
<b>Model Year Start:</b> 2024	<b>Model:</b> Land Cruiser	<b>Prod Date Range:</b> [02/2024 -     ]
<b>Title:</b> EXTERIOR PANELS / TRIM: BACK DOOR OUTSIDE GARNISH: DISASSEMBLY; 2024 MY Land Cruiser [02/2024 -     ]		

DISASSEMBLY

CAUTION / NOTICE / HINT


COMPONENTS (DISASSEMBLY)



PROCEDURE		PART NAME CODE			
1	PRECAUTION	-	<a href="#">INFO</a>	-	-
2	NO. 1 REAR NAME PLATE	75441	<a href="#">INFO</a>	-	-
3	BACK DOOR OUTSIDE GARNISH PROTECTOR	76825	<a href="#">INFO</a>	-	-
4	BACK DOOR OUTSIDE GARNISH PROTECTOR	76825C	<a href="#">INFO</a>	-	-

*A	for Type A	-	-
----	------------	---	---

•	Non-reusable part	-	-
---	-------------------	---	---



PROCEDURE		PART NAME CODE			
2	NO. 1 REAR NAME PLATE	75441	<a href="#">INFO</a>	-	-
3	BACK DOOR OUTSIDE GARNISH PROTECTOR	76825	<a href="#">INFO</a>	-	-
4	BACK DOOR OUTSIDE GARNISH PROTECTOR	76825C	<a href="#">INFO</a>	-	-
5	NO. 2 BACK DOOR OUTSIDE GARNISH	76812A	-	-	-
6	BACK DOOR GARNISH SIDE PROTECTOR LH	76822D	<a href="#">INFO</a>	-	-
7	BACK DOOR GARNISH SIDE PROTECTOR RH	76821C	<a href="#">INFO</a>	-	-
8	LOWER BACK DOOR OUTSIDE GARNISH MOULDING LH	76816B	-	-	-
9	LOWER BACK DOOR OUTSIDE GARNISH MOULDING RH	76815C	-	-	-

*A	for Type B	-	-
•	Non-reusable part	-	-

# **PROCEDURE**

## **1. PRECAUTION**

**NOTICE:**


When removing parts with double-sided tape applied, heat the portion of the parts with tape residue with a heat light if the double-sided tape is difficult to remove.

Standard Value:

PART	TEMPERATURE
Metal parts	40 to 60°C (104 to 140°F)
Resin parts	20 to 30°C (68 to 86°F)

**CAUTION:**

- Do not touch the heat light and heated parts.
- Touching the heat light may result in burns.
- Touching heated parts for a long time may result in burns.



*a	Heated Part
*b	Heat Light


**NOTICE:**

Do not heat the part excessively.

**2. REMOVE NO. 1 REAR NAME PLATE**


Click here [INFO](#)

**3. REMOVE BACK DOOR OUTSIDE GARNISH PROTECTOR**




- (1) Heat the adhesive of the back door outside garnish protector using a heat light.
- (2) Remove the back door outside garnish protector.

#### 4. REMOVE BACK DOOR OUTSIDE GARNISH PROTECTOR




- (1) Heat the adhesive of the back door outside garnish protector using a heat light.
- (2) Remove the back door outside garnish protector.
- (b) Use the same procedure for the other side.

#### 5. REMOVE NO. 2 BACK DOOR OUTSIDE GARNISH (for Type B)



#### 6. REMOVE BACK DOOR GARNISH SIDE PROTECTOR LH (for Type B)



*a	Double-sided Tape	-	-
----	-------------------	---	---


(1) Heat the adhesive of the back door garnish side protector LH using a heat light.

(2) Detach the guide and remove the back door garnish side protector LH.

## 7. REMOVE BACK DOOR GARNISH SIDE PROTECTOR RH (for Type B)

(a) Use the same procedure described for the LH side.

## 8. REMOVE LOWER BACK DOOR OUTSIDE GARNISH MOULDING LH (for Type B)



## 9. REMOVE LOWER BACK DOOR OUTSIDE GARNISH MOULDING RH (for Type B)

(a) Use the same procedure described for the LH side.

