

Last Modified: 07-05-2024	6.11:8.1.0	Doc ID: RM100000002JRHH
Model Year Start: 2024	Model: Land Cruiser	Prod Date Range: [02/2024 -]
Title: AUDIO / VIDEO: FRONT DOOR SPEAKER: REMOVAL; 2024 MY Land Cruiser [02/2024 -]		


REMOVAL




CAUTION / NOTICE / HINT

HINT:

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

COMPONENTS (REMOVAL)



PROCEDURE		PART NAME CODE			
1	FRONT DOOR UPPER TRIM COVER LH	67782	INFO	-	-
2	FRONT DOOR ARMREST COVER SUB-ASSEMBLY LH	74038	INFO	-	-
3	FRONT DOOR TRIM BOARD SUB-ASSEMBLY LH	67602	-	-	-
4	FRONT NO. 1 SPEAKER ASSEMBLY	86160	INFO	-	-

PROCEDURE

1. REMOVE FRONT DOOR UPPER TRIM COVER LH



Click here [INFO](#)

2. REMOVE FRONT DOOR ARMREST COVER SUB-ASSEMBLY LH



Click here [INFO](#)

3. REMOVE FRONT DOOR TRIM BOARD SUB-ASSEMBLY LH

Click here [INFO](#)

4. REMOVE FRONT NO. 1 SPEAKER ASSEMBLY



NOTICE:

Do not touch the cone of the front No. 1 speaker assembly.

