

<b>Last Modified:</b> 07-05-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000002JTS8
<b>Model Year Start:</b> 2024	<b>Model:</b> Land Cruiser	<b>Prod Date Range:</b> [02/2024 -     ]
<b>Title:</b> MIRROR (EXT): OUTER REAR VIEW MIRROR: REMOVAL; 2024 MY Land Cruiser [02/2024 -     ]		

REMOVAL

CAUTION / NOTICE / HINT

The necessary procedures (adjustment, calibration, initialization, or registration) that must be performed after parts are removed and installed, or replaced during outer rear view mirror assembly with cover removal/installation are shown below.

Necessary Procedures After Parts Removed/Installed/Replaced


REPLACED PART OR PERFORMED PROCEDURE	NECESSARY PROCEDURES	EFFECT/INOPERATIVE FUNCTION WHEN NECESSARY PROCEDURES ARE NOT PERFORMED	LINK
<ul style="list-style-type: none"><li>• Side television camera assembly LH (Including removal and installation)</li><li>• Outer rear view mirror assembly LH (Including removal and installation)</li><li>• Side television camera assembly RH (Including removal and installation)</li><li>• Outer rear view mirror assembly RH (Including removal and installation)</li></ul>	Side television camera view adjustment	<ul style="list-style-type: none"><li>• Panoramic View Monitor System</li><li>• Multi-terrain Monitor system</li></ul>	<div>INFO</div>
<ul style="list-style-type: none"><li>• Front television camera assembly, radiator grille assembly or front bumper assembly</li><li>• Rear television camera assembly</li><li>• Side television camera assembly LH or outer rear view mirror assembly LH</li><li>• Side television camera assembly RH or outer rear view mirror assembly RH</li></ul>	Television camera view adjustment  <b>HINT:</b> Replacement or removal and installation of 2 or more parts		




CAUTION / NOTICE / HINT

HINT:

- Use the same procedure for the RH side and LH side.
- The following procedure is for the LH side.


COMPONENTS (REMOVAL)




PROCEDURE		PART NAME CODE			
1	FRONT DOOR UPPER TRIM COVER LH	67782	<a href="#">INFO</a>	-	-
2	FRONT DOOR ARMREST COVER SUB-ASSEMBLY LH	74038	<a href="#">INFO</a>	-	-
3	FRONT DOOR TRIM BOARD SUB-ASSEMBLY LH	67602	-	-	-
4	OUTER MIRROR INSTALL HOLE COVER	87964	-	-	-
5	HOLE PLUG	-	-	-	-
6	OUTER REAR VIEW MIRROR ASSEMBLY LH	87940	<a href="#">INFO</a>	-	-

# **PROCEDURE**

## **1. REMOVE FRONT DOOR UPPER TRIM COVER LH**

	Click here <a href="#">INFO</a>
-------------------------------------------------------------------------------------	---------------------------------

## **2. REMOVE FRONT DOOR ARMREST COVER SUB-ASSEMBLY LH**

	Click here <a href="#">INFO</a>
-------------------------------------------------------------------------------------	---------------------------------

## **3. REMOVE FRONT DOOR TRIM BOARD SUB-ASSEMBLY LH**

Click here [INFO](#)


**4. REMOVE OUTER MIRROR INSTALL HOLE COVER**

Click here [INFO](#)

**5. REMOVE HOLE PLUG**


Click here [INFO](#)

**6. REMOVE OUTER REAR VIEW MIRROR ASSEMBLY LH**



*A	w/ Panoramic View Monitor System	*B	w/o Panoramic View Monitor System
----	----------------------------------	----	-----------------------------------

- (1) w/ Panoramic View Monitor System:
  - 1. Disconnect the 3 connectors and detach the wire harness clamp.
- (2) w/o Panoramic View Monitor System:
  - 1. Disconnect the connector and detach the wire harness clamp.



- (1) Remove the 3 nuts.

**NOTICE:**  
Hold the outer rear view mirror assembly LH with one hand so that it does not drop.

- (2) Detach the claw and guide to remove the outer rear view mirror assembly LH.

